


OPERATION MANUAL PRO SERIES WIDE BELT SANDER

MSANWB25X60-1K-7.5-0197-1



INDEX

GENERAL SAFETY RULES -----	1
SPECIFIC SAFETY RULES -----	2
BEFORE OPERATION -----	3
INSTALLATION -	
STEP 1. MOVING THE MACHINE -----	4
STEP 2. CLEANING THE MACHINE -----	4
STEP 3. POWER WIRE CONNECTIONS -----	4
STEP 4. AIR CIRCUIT CONNECTION -----	5
STEP 5. DUST HOOD CONNECTION -----	5
STEP 6. INSTALL SANDING BELT -----	6
MAJOR PARTS OF THE MACHINE -----	7
BRAKE SYSTEM -----	8
CONTROL PANEL FEATURES -----	9
OPERATION OF DIGITAL PANEL -----	10
TABLE MOVEMENT -----	10
TROUBLE SHOOTING FOR DIGITAL CONTROL PANEL -----	11
ADJUSTMENT -	
SANDING BELT TENSION -----	12
SANDING BELT TRACKING -----	12
SANDING PLATEN POSITION -----	13
SANDING BELT OSCILLATION SPEED -----	13
V-BELT TENSION ADJUSTMENT -----	14
CONVEYOR BELT -----	14
FEED SPEED -----	15
PRESSURE ROLLER -----	15
TROUBLE SHOOTING -----	16
LUBRICATION AND MAINTENANCE -----	16
WIRE DIAGRAM -----	17
PARTS EXPLODED VIEW -----	18~37



GENERAL SAFETY RULES

READ THE MANUAL: Read, understand and follow the safety and operating instructions found in this manual. Know the limitations and hazards associated with the Wide Belt Sander.

WORK AREA: Keep the floor around the machine clean and free of scrap material, sawdust, oil or grease to minimize the danger of tripping or slipping. Mark off the machine area, make sure it is well lighted, and includes a proper exhaust system to minimize dust.

ELECTRICAL GROUNDING: Your machine must be electrically grounded. If a cord and plug are used, make sure the plug connects to a suitable ground. Follow the grounding procedure indicated by the National Electrical Code. Keep power tools in dry areas free from moisture.

PROTECTION: Take every precaution to protect yourself, others around you, and the machine itself from improper use.

CARELESS ACTS: Give the work you are doing your complete, undivided attention. Horseplay, looking around, and talking to someone are careless acts that can result in serious injury. All children and visitors should be kept a safe distance from your work area.

CHECK DAMAGED PARTS: Before continuing use of the machine, a guard or other part that is damaged should be carefully checked to ensure that it will operate properly and safely and perform its intended function. Check for alignment of moving parts, binding of moving part, breakage of parts mounting and any other conditions that could affect its operation. A guard or other part that is damaged should be properly repaired or replaced before machine operation continues.



GENERAL SAFETY RULES

DO NOT OVER-REACH: Maintain a balanced distance and keep your body under control at all times. Do not over-reach or use excessive force to perform any machine operation.

EYES: Always wear approved safety goggles, glasses or a face shield when operating the sander. There are no exceptions to this rule.

DRESS CODES: This machine can cause injury by catching loose clothing, jewelry, hair and gloves. Do not wear anything loose such as clothing, neckties, jewelry or gloves that can get caught in moving parts. Confine long hair, avoid wearing rings and watches, and keep sleeves above the elbow while operating this machine.

HOUSEKEEPING: Before turning on machine, remove all extra equipment such as keys, wrenches, scrap and cleaning rags away from the sander. Keep the area around the machine clean and free of sawdust to minimize danger of slipping.

POWER ON: Before connecting power to the sander, make sure the start switch is in the "OFF" position.

POWER OFF: Make sure the sander is unplugged or electrically disconnected and locked out before performing maintenance, checking belts or service work.



SPECIFIC SAFETY RULES

READ THE MANUAL: Do not operate the wide belt sander until you read, understand and are able to follow the safety instructions found in this manual. Know what the wide belt sander can safely do, and what it can not do. Safety rules and caution decals are placed on the machines as reminders of good safety practices.

HAND SAFETY: Keep hands clear while feeding parts onto the conveyor table. The part will be forced down as it begins to feed into the machine, causing a pinching action between the part and the table. Use caution ! Hands should be clear of the stock and the table to avoid pinching.

PROTECT YOURSELF: Protect yourself at all times when operating the wide belt sander. Avoid eye injury by wearing approved safety shields, goggles or glasses at all times. Wear protected footwear. Steel toed shoes are recommended because heavy parts can fall off the conveyor table onto feet.

KEEP GUARDS IN PLACE: Do not operate the sander with guards off. Keep the guards in place at all times when the machine is running. If removed for maintenance purposes or any other reason, use extreme caution and replace the guards upon completion of the task and before using the machine again. Injury can result from exposure to the machine's internal moving parts.

NEVER REACH : Never reach into a running machine. Turn off electrical power and stop machine before attempting to retrieve parts from within the machine. Contact with internal moving parts can result in loss or injury to fingers, hands and arms.

DO NOT LEAVE UNATTENDED: The operator of the sander is responsible for shutting the machine down when it is not in use.

CAUTION: The abrasive belt will coast to a stop in normal conditions, and will only break to a stop when the emergency devices are pressed!
IT IS DANGEROUS TO LEAVE A MACHINE.



SPECIFIC SAFETY RULES

UNATTENDED: Person not familiar with the sander's operation could injure themselves or others.

OPERATION POSITION: Stand to one side of the conveyor table and make sure no one else is standing in line with the table while feeding into the machine. The wide belts sander operates at a high speed and should a part slip, it will exit the machine at a high rate of speed and may result in injuries to anyone standing directly in front of the infeed. (Keep conveyor belt clean and check pin-roll adjustments)

WORKING MATERIAL: Do not attempt to sand working piece shorter than 9" (289mm) long without butting a board of equal thickness behind it to help stock through the machine. Boards less than 9" long can not be held secure enough for safe operation of this machine.

MAINTAIN TOOLS: Keep all tools sharp and clean for the best and safest performance and follow instructions for lubricating and changing accessories. Never stand on the machine. Serious injury could occur if the sander is tipped or if the sanding belt is accidentally contacted.

DISCONNECT POWER: Make sure sander is unplugged before performing maintenance or adjustments.

IF YOU ARE NOT thoroughly familiar with the operation of wide belt sanders, obtain device from your supervisor or other qualified person.

DRUGS, ALCOHOL, MEDICATION: Do not operate tool while under the influence of drugs, alcohol or any medication.

WARNING: The dust generated by certain woods and wood products can be dangerous to your health. Always operate machinery in well ventilated areas and provide for proper dust removal. Use wood dust collection systems whenever possible.



BEFORE OPERATION


Before operating sander, make sure that :

1. Dust collection system is turned on.
2. Sanding belt specification is correct
3. Sanding belt is running in proper direction
4. Sanding belt tension is correct
5. All screws and handles are tightened securely.
6. Working air pressure is correct, normal working pressure is 4-5 kg/cm²
Do not operate sander until normal pressure is reached.
7. Sanding belt is tracking correctly
8. Conveyor belt is tracking correctly
9. Thickness is correctly set
10. Feed speed is correctly set

INSTALLATION-


STEP 1. MOVING THE MACHINE

The machine should be moved to the work site with a fork lift. Make sure that the fork lift's loading capacity is adequate for the machine's weight. The forks must protrude from the far side of the machine bottom when moving. Pay careful attention to the machine balance while it is being moved, and make sure it does not strike the floor when being placed at the work site.



STEP 2. CLEANING THE MACHINE

Anti-corrosive oil is applied to the machine before shipment. After unpacking, using a cloth soaked in kerosene to clean the anti-corrosive oil from the machine. Do not use lacquer thinner or any volatile solvents, as they can damage the surface of the machine.



STEP 3. POWER WIRE CONNECTIONS


Before connecting the power wires of the machine to the power supply, make sure the voltage, hertz, phase and amperage are compatible. The prewired voltage of the machine is indicated on the electrical indication plate.

The power source connection points are located inside the control box and are marked R.S.T. for 3-phase and R.S. for 1-phase. The ground wire connection point is marked "E". See Figure 1.

Once the wiring is completed, turn the machine on, press the conveyor table raising switch and see if the table moves the same direction indicated on the switch, if it does not, turn the machine off and switch any two of the three power source wires.

WARNING !!

ELECTRICAL WIRING SHOULD BE DONE BY A QUALIFIED ELECTRICIAN. THE MACHINE MUST BE PROPERLY GROUNDED TO HELP AVOID ELECTRIC SHOCK AND ASSOCIATED HAZARDS INCLUDING POSSIBLE DEATH.



STEP 4. AIR CIRCUIT CONNECTION

The air circuit connector is on the Filter/Regulator unit located on the back side of sander. Connect your air supply to the 5/16" air source connector with a flexible hose. The working pressure of the machine can be adjusted from the pressure regulator. Set the pressure by lifting the adjustment knob and rotate it clockwise to increase pressure, counter-clockwise to decrease pressure. When the correct pressure is set, push the knob down to lock it in place. **See Figure 2.** The recommended working pressure is 4-5 kg/cm²




Figure 2

STEP 5. DUST HOOD CONNECTION

Connect your dust collection system to the machine's dust hood (located on top) with a 4" diameter. Make sure the dust collector has sufficient capacity for the machine. **See Figure 3**

NOTICE:

ALWAYS TURN ON THE DUST COLLECTOR BEFORE OPERATING THE SANDER.




Figure 3

INSTALL SANDING BELT

1. Disconnect machine from power source
2. Shut "OFF" the air tension switch (C).
3. Remove the pad lock lever (D) by turning it counterclockwise.
4. Remove the pad block (E)
5. Remove the old belt by sliding it out the end

(See Figure 4)




Figure 4

INSTALL SANDING BELT

6. Insert new belt by starting first on the upper roller (F), then the lower roller. Center the belt while avoiding contact with limit switch fingers that are located on each side of the belt.

NOTICE !!



Make sure the direction of the arrows on the inside of the belt matches the rotation of the machine. Check that the edges of the sanding belt are not chipped or torn.

7. Replace pad block (E) and tighten pad lock lever (D).
8. Turn "ON" the air tension switch (C)
9. Make sure there is clearance between the belt edges and limit switch fingers on either side. If there is not, make the appropriate belt corrections according to the procedure above (with the air tension turned off) as necessary.

NOTICE !!

Machine will not start if a limit switch is depressed.

MAJOR PARTS OF THE MACHINE --



BRAKE SYSTEM

The sander will stop automatically if any of the follow occur -

1. No air supply to the machine
2. No sanding belt mounted
3. Improper belt tension
4. Sanding belt rubs out of track
5. If the sanding belt breaks, all movement will be stopped, through the conveyor table can still be raised or lowered.
6. Once the machine has stopped, the operator should find where the braking sustem was tripped, and make the necessary adjustments. The machine can then be reset and restarted.

See Figure 5. for the location of limit switches.




Figure 5

CONTROL PANEL FEATURES

Figure 6





Figure 7



OPERATION OF DIGITAL PANEL

CALIBRATION:

1. Calibrate the digital readout by first measuring the thickness of your workpiece.
2. Input the correct figure to match the workpiece thickness and press "SET" for 2-5 seconds.

INPUT OF DATA:

1. Press any of the number buttons and "000.0" will appear on the display.
2. Input the correct figure with the number buttons, then press "SET" for 2-3 seconds.
3. The display will begin flashing and then stop, with the new data on the display.
4. Alternatively, you may set the new input by pressing the + or- buttons until the proper figure is reached. NOTE: The INPUT and RUN lights will be illuminated at the same time.
5. Press "START"(The INPUT and RUN lights will be illuminated at the same time). The control unit will begin to run and the figure on the display will change back to 0, then it will start to increase up to the figures that were inputted.

TABLE MOVEMENT

Table height can be adjusted manually or with the digital key pad.
See Figure 7

MANUAL TABLE MOVEMENT:

Turn the handwheel located under the front of the infeed table for manual table positioning.

MOTORIZED TABLE MOVEMENT:

Press the TABLE UP or TABLE DOWN key once for motorized table positioning in 0.005" (0.1mm) increments.

NUMERICAL KEY PAD:

Enter the position of sand depth.

METRIC OR STANDARD KEY:

Press and hold the SET button for 3 seconds to calibrate display at the current board thickness; or press and hold key for 10 seconds to toggle the display between metric and standard measurement.

TABLE START:

Moves table to a preset sanding depth

TABLE STOP:

Stops table movement immediately

DIGITAL DISPLAY:

Show final table sanding depth.

TROUBLE SHOOTING FOR DIGITAL PANEL:

PROBLEM		POSSIBLE CAUSE		SOLUTION
The display fails to show figures		1.Electric pressure of the 220V or AC110V is abnormal 2. Fuse us burned out 3. Control unit is out of order		1.Re-input correct electric pressure 2.Replace 1A fuse 3.Unit must be repaired or replaced by authorized service personnel
Display shows abnormal figures		1. Wrong figures were input 2. Parameter is incorrect		1. Input the proper numbers in accordance with the actual dimensions 2. Caculate correct parameter and input it *If the above steps are ineffective, turn the power off and then on. If it is still not working properly, it should be repaired or replaced.
Display shows figures, but they do not change in conjunctions with the hoist motor's operation.		1. Proximity switch is not functioning (a functioning prox-switch will cause the light on the induction switch to be illuminated or put out depending on movement of the table) 2. Distance between induction until and induction sheet is more than 2mm.		1. Change proximity switch 2. Adjust distance between induction unit and induction sheet to less than 1 mm
Travel dimension incorrect		1. Control unit parameter is not in harmony with the table		1. Connect control unit parameter

ADJUSTMENT --

SANDING BELT TENSION

The tension of sanding belt is controlled by an air cylinder. Turn the tension air switch to tighted or loosen the sanding belt tension. When the machine is not in use, release the sanding belt tension to avoid sanding belt fatigure.

"A" - Tracking Adjustment Lever

"C" - Air Tension Switch





Figure 8

SANDING BELT TRACKING

If the sanding belt runs outside of the normal track, the machine will stop automatically. When replacing the sanding belt, there may be a length tolerance between the right and left sides of the belt which may result in the incorrect tracking of the sanding belt. If this occurs, it will be necessary to adjust the tracking:

1. The degree of sanding belt oscillation to the right side and to the left should be equal. For example, if the oscillation time to the right is one second ,then the oscillation time to the left is one second.
2. If the oscillation time to the right is one second, but the oscillation time to the left is longer , then loosen the tracking adjustment lever. See Figure 8 and move it to the left until proper tracking is achieved. When satisfied,tighten the lever.
3. If the oscillation time to left is one second, but the oscillation time to the right is longer, then loosen the tracking adjustment lever and move it to the right until proper tracking is achieved. Tighten adjustment lever.



SANDING BELT OSCILLATION SPEED

The sanding belt oscillation is controlled by the air cylinder.

Oscillation speed can be adjusted by means of the speed controller on the cylinder, see **Figure 10**.

Loosen the fixing nut on the speed controller, then turn controller clockwise to decrease oscillation speed. Turn counter-clockwise to increase oscillation speed.

The hole in the air eye should be checked frequently. If it becomes blocked with dust, it may casue the sanding belts to run out of its normal track and the mahcine will shut off. In the event of blackage, this hole should be cleaned.




Figure 10

V-BELT TENSION ADJUSTMENT

After the machine has been in operation for a long time, the V-belt may become slightly loose. Should this occur, there will be an abnormal sound while the motor is running. Adjust the V-belt as follow.

Figure 11: Slightly loose the lock unit that tightens the motor base, and turn the adjustment screw until correct tension is achieved.

Re-tighted lock nut.




Figure 11

CONVEYOR BELT

The conveyor belt should always run at the center of the contact drum. If it approaches either to the left or right, adjustment is necessary. First check that the conveyor belt tension is correct. If the tension is too loose, adjust this first before you adjust the tracking.

See Figure 12

CONVEYOR BELT TENSION:

1. Disconnect the sander from the power source.
2. Remove from brake cover by removing the four screw.
3. Turn both adjustment rod clockwise equally to increase tension.

CONVEYOR BELT TRACKING:

1. Turn the conveyor belt "ON"
2. If the belt is tracking to the **right** side of the table, turn the **right** adjustment rod clockwise.
3. If the belt is tracking to the **left** side of the table, turn the **left** adjustment rod clockwise.

NOTICE !!

THE EDGE OF THE CONVEYOR BELT SHOULD JUST TOUCH THE GUIDE WHEELS.




Figure 12

FEED SPEED

(FOR VARIABLE SPEED ONLY)

The feed speed adjustment is infinitely variable in order to meet the sanding requirements of a wide variety of materials. In general, soft woods require a higher feed speed, while hard woods require a lower feed speed. However, correct feed speed selection is largely a matter of experience.

CAUTION !!

CHANGE THE FEED SPEED ONLY WHILE THE MACHINE IS RUNNING.

Adjust the feed speed with the speed selector knob of the worm gear reducer. **Figure 13**, and the speed adjustment valve of the hydraulically driven conveyor belt. Turn the feed speed selector knob clockwise to decrease the conveyor belt speed, counter-clockwise to increase it.




Figure 13

PRESSURE ROLLER

The front and rear pressure rollers have been factory adjusted. However, if further adjustment is ever required, proceed as follows:

1. Stop machine
2. Place a sanded panel on the conveyor belt and under the rollers. The panel should be long enough to contact both front and rear rollers. Raise the table until panel contacts the rollers.
3. Make sure the pressure at the right and left side of pressure rollers is even
4. Loosen the fix nut then turn the adjustment knob as shown in **Figure 14**.
5. When parallelism is satisfactory, retighten the fix nut.




Figure 14

PROBLEM	POSSIBLE CAUSE	SOLUTION
Sanding belt clogs too quickly	1. Grit of sanding belt is too fine 2. Sanding overload 3. Too much oil, dirt on wood surface	1. Replace with larger grit 2. Reduce sanding load. 3. Clean wood, or use better work
Too many roundings created along the edge while sanding solid wood	1. Too much material being removed	1. Reduce the amount of material being removed
Uneven thickness between the left and right sides of the workpiece	1. Conveyor table not parallel with contact roller 2. Conveyor belt worn out 3. Graphite cloth and carpet on the pad are worn out	1. Adjust conveyor table / contact roller to parallel 2. Replace conveyor belt 3. Replace graphite cloth and carpet
Uneven thickness between the front and rear ends of the workpiece	1. Feed speed too fast 2. Sanding overload 3. Grit of sanding belt too fine 4. Unequal position of pressure plate	1. Reduce rate of feed 2. Reduce sanding load 3. Use large grit sanding belt 4. Adjust pressure plate to produce equal pressure on stock
Workpiece slips on the conveyor belt	1. Too much pressure from pressure plate 2. Dirty conveyor belt 3. Conveyor belt is worn out	1. Reduce force from pressure plate 2. Clean conveyor belt 3. Replace conveyor belt
Straight notches on workpiece surface	1. Dirty pressure plate 2. Contact drum is scratched 3. Graphite cloth and carpet on the pad are worn out	1. Clean pressure plate 2. Replace drum 3. Replace cloth and carpet
Snake markings on workpiece	1. Sanding belt partially damaged 2. Worn area on sanding belt	1. Repair/replace sanding belt 2. Replace sanding belt
Cross-parallel stripes across the entire width of workpiece	1. Sanding belt joint is too thick 2. Worn areas on sanding belt 3. Sanding load not less than 0.0mm	1. Replace sanding belt 2. Replace sanding belt 3. Reduce sanding load to less than 0.0mm


LUBRICATION AND MAINTENANCE:

1. The machine interior should be thoroughly cleaned every day after work. It is important to remember to remove the sanding belt before cleaning and replace it afterwards.
2. The bearings should be greased after every 150 work hours.
3. If the machine is equipped with a hydraulic power system, the hydraulic oil should be renewed after every 6000 work hours.
4. The water should be released from the filter cup regularly
5. Make sure that there is an adequate oil film on the table jack screws (support screws) at all times.
6. The oil inside the gear reducer should be changed after the first 300 hours of operation, and every 2500 hours of use thereafter. Recommended oil is #140 gear oil.








GENERAL ELECTRICAL DIAGRAM

MSANWB25x60-1K-7.5-0197-1


(Single phase)



0000




0000	
ITEM NO	DESCRIPTION
002	LIMIT SWITCH TUBE
003	TOOL BOX
006	KEY
007-1	SANDING BELT #100
007-2	SANDING BELT #180
008	PHILLIP'S SCREWDRIVER
009	FLAT SCREW DRIVER
010	WRENCH 8 X 10
011	WRENCH 12 X 14
012	WRENCH 17 X 19
013	HEX WRENCH




1000		1000	
ITEM NO	DESCRIPTION	ITEM NO	DESCRIPTION
101	MACHINE FRAME	126	LIMIT SWITCH
102	MOTOR BASE	127	LIMIT SWITCH PLATE
103	MOTOR BASE HINGE	128	SCREW 1/4" X 1/2"
104	NUT 1/2"	129	PLAIN WASHER 1/4"
105	MOTOR BASE ADJUSTMENT ROD	132	FLAT HEAD SCREW
106	SPRING WASHER 1/2"	133	SPRING WASHER
107	SCREW	301	BRAKE BRACKET
108	PLAIN WASHER 1/2"	301-1	BRAKE BRACKET FRONT GUARD
109	MOTOR	302-1	BRAKE LINING
109-1	FAN	302-2	BRAKE LINING
109-2	FA COVER	303	BRAKE ARBOR
110	PULLEY	304	BRAKE SPRING
111	HEX SOCKET HEAD SCREW 5/16" X 1 1/4"	305	BRAKE INSIDE PIECE
112	SPRING WASHER 5/16"	306	FLAT HEAD SCREW 1/4" X 1/2"
113	KEY	307	BRAKE PIN
114	SCREW 5/16" X 1"	308	HEX SOCKET HEAD SCREW
115	SPRING WASHER 5/16"	310	SPRING WASHER 3/8"
116	DISC BRAKE	311	NUT 3/8"
118	PULLEY BUSHING	312	HEX SOCKET HEAD SCREW 1/4" X 5/8"
119	BELT	313	BRAKE GASKET
121	BRAKE BRACKET		
122	PLAIN WASHER 3/8"		
123	SCREW 3/8" X 3/4"		
124	FLAT HEAD NUT		
125	HEX SOCKET HEAD SCREW 1/4" X 3/4"		

2000




2000		2000	
ITEM NO	DESCRIPTION	ITEM NO	DESCRIPTION
101	ELEVATION SCREW	320	HEADLESS SCREW 1/4" X 1/2"
102	SCREW 5/16" X 1"	321	HAND WHEEL
103	PLAIN WASHER 5/16"	322	MOTOR BASE
104	SPRING WASHER 5/16"	323	SCREW 1/4" X 1"
105	SPRING WASHER 3/8"	325	MOTOR BASE ADJUSTMENT ROD
106	SCREW 3/8" X 1"	326	PLAIN WASHER 1/2"
107	ELEVATION SLIDE	327	NUT 1/2"
108	DUST GUARD BELLOW	328	SPRING WASHER 1/2"
109	SCREW 5/16" X 3/4"	331	MOTOR
110	SPRING WASHER 5/16"	332	NUT 1/4"
111	CHAIN	333	SCREW 1/2" X 4 1/2" LONG
		339	KEY 5/16" X 20MM
201	NUT HOUSING	340	KEY
202	NUT	341	KEY
203	THRUST BEARING 51107		
204	"C" CIRCLIP S 35	401	SPROCKET WHEEL ADJUSTMENT PIECE
206	SPROCKET WHEEL	402	SPROCKET WHEEL SHAFT
		403	BEARING 6003ZZ
301	ELEVATION GEAR BOX	404	ADJUSTMENT SPROCKET WHEEL
302	WORM GEAR	405	SPROCKET WHEEL ADJUSTMENT ROD
303	BEARING 6005Z	406	PLAIN WASHER 3/8"
304	BEARING CAP	407	NUT 3/8"
305	HEX SOCKET HEAD SCREW 1/4" X 3/4"	408	NUT 5/16"
306	WORM SHAFT	409	SPRING WASHER 5/16"
307	BEARING 6002Z	410	SCREW 5/16" X 3/4"
308	BEARING CAP	411	MOTOR BASE
309	HEX SOCKET HEAD SCREW		
310	BEARING CAP		
311	HEX SOCKET HEAD SCREW 1/4" X 5/8"		
312	SPROCKET WHEEL		
313	HEADLESS SCREW 5/16" X 1/2"		
314	PULLEY		
315	BELT		
316	PULLEY		
317	HEADLESS SCREW 1/4" X 1/2"		
318	SPRING WASHER 5/16"		
319	SCREW 5/16" X 3/4"		




3000		3000	
ITEM NO	DESCRIPTION	ITEM NO	DESCRIPTION
101	CONVEYOR TABLE	140	FRONT BRAKE COVER
102	CONVEYOR BELT	141	ROUND PHILLIP'S SCREW 1/4" X 1/2"
103	REDUCER FIX PLATE	142	LIMIT SWITCH
104	PLAIN WASHER 3/8"	143	ROUND PHILLIP'S SCREW
105	SPRING WASHER 3/8"	144	SCREW 1/2" X 3" LONG
106	HEX SCREW 3/8" X 1 1/2"	145	SPRING WASHER 3/8"
107	OUTFEED ROLLER	146	HEX SCREW 3/8" X 1 1/4"
108	BEARING UCF 205		
109	COVER FOR CHAIN GEAR		
110	SPRING WASHER 3/8" x 4"	201	INFEED ROLLER SHAFT
111	HEX SCREW 3/8" X 1 1/2"	202	INFEED ROLLER
112	BRAING UCF 205	203	BEARING
113	SPRING WASHER 3/8"	204	"C" CIRCLIP S30
114	SCREW 3/8" X 1 1/4"	205	ELEVATION ALUMINUM LIMITER
115	BEARING CAP	206	HEX SOCKET HEAD SCREW
116	DRIVEN PULLEY		
117	SCREW 3/8" X 1 1/2"		
118	GEAR 5/8"x 22T x 5/8" x 26T		
119	KEY 7MM X 55MM		
120	SET SCREW 5/16"x1/2"		
121	CHAIN 5/8" x 50		
122+123	MOTOR WITH REDUCER		
124	GEAR 5/8"x 14T x 5/8" x 18T		
126			
127			
128			
129	SPRING WASHER 1/4"		
130	ROUND PHILP SCREW 1/4" x 3/4"		
131	INFEED ROLLER BRACKET		
132	HEX SOCKET HEAD SCREW 3/8" X 3/4"		
133	INFEED ROLLER BRACKET		
135	CONVEYOR BELT POSITIONING WHEEL		
136	HEX SOCKET HEAD SCREW 5/16" X 2"		
137	SPRING WASHER 5/16"		
138	NUT 5/16"		

4000




4000	
ITEM NO	DESCRIPTION
103	SPRING 3 X 15.6 X 57
107	HEX NUT 3/8"-18
108	HEX BOLT 5/16"-18 x 1-1/4"
109	LOCK WASHER 5/16"
201	PISTON ROLLER SHAFT
202	PISTON ROLLER
203	BEARING 6001 2RS
204	SHAFT BEARING COLLAR
205	HEADLESS SCREW 1/4"-20x3/4"
206	HEX NUT 1/4"
301	PISTON ROLLER ADJ. ROD
302	PISTON BRACKET
303	PIN 3x27MM
304	PISTON SLIDERAIL




5000	
ITEM NO	DESCRIPTION
104	BEARING UCC206
103	LOCK WASHER 5/16"
107	KEY 5/16"x5/16"x 30MM
110	LOCK WASHER 1/2"
111	CAP SCREW 1/2"-12 x 1-1/2"
112	CAP SCREW 1/4"-20 x 1/2"
114	FILTER
115	GREASE FITTING 1/16 W/CAP 90 DEG
116	PLUG 30mm
118	PHLP HD SCR 1/4"-20 x 1/2"
203	CAP SCREW M6-1.0 x 6
205	HANDLE
206	ROLLER LOCKDOWN SHAFT
401	BEARING HOUSING
402	RUBBER ROLLER
403	FASTENING TUBE
405	PULLEY
406	CAP SCREW 5/16"-18 x 1-1/4"
407	BEARING HOUSING
408	BEARING BRACKET PAD
409	BEARING 6205-2RS
410	SCREW CAP
411	BEARING CAP
417	PULLEY COVER

6000




6000		6000	
ITEM NO	DESCRIPTION	ITEM NO	DESCRIPTION
101	SQUARE FRAME	201	UPPER ROLLER BRACKET
103	SQUARE FRAME SEAL (RIGHT)	202	UPPER ROLLER
104	SQUARE FRAME SEAL (LEFT)	203	UPPER ROLLER BRACKET
105	FLAT HEAD SCREW 1/4" X 1/2"	204	BEARING UCC205
106	SPRING WASHER 3/8"	205	HEADLESS SCREW M6 X 6MM
107	SCREW 3/8" X 1"	206	HEX SOCKET HEAD SCREW
108	SPRING WASHER 1/2"	207	SPRING WASHER 3/8"
109	SCREW 1/2" X 1"	208	FILTER
111	HEX SOCKET HEAD SCREW 5/16" X 3/4"		
112	SCREW M8 X 20MM	301	TRIMMING SCREW
113	AIR CYLINDER	302	ECCENTRIC ROD
114	LIMIT SWITCH HOLDER (L TYPE)	303	HEX SOCKET HEAD SCREW 1/2" X 3 1/2"
115	LIMIT SWITCH	304	PLAIN WASHER 1/2"
116	LIMIT SWITCH TUBE	305	ECCENTRIC PIECE
117	LIMIT SWITCH HOLDER	306	UNIVERSAL JOINT FORK
118	AIR SENSOR NOZZLE (FEMALE)	310	NUT 1/2"
119	AIR CYLINDER BRACKET	320	FRAME OF ECCENTRIC SHAFT
120	AIR SENSOR NOZZLE (MALE)	322	SPRING WASHER 3/16"
121	THROTTLE VALVE	323	NUT 5/16"
122	THROTTLE VALVE BASE	324	SPRING M4 X 12L
123	PLATE	325	HEX SOCKET HEAD SCREW 5/16" X 3/4"
124	ALUMINUM DISC	326	SCREW M5 X 8L
125	OIL CAP	327	AIR CYLINDER 30*4
126	ALUMINUM PLATE		
127	SCREW M4 X 20MM		
128	SANDING BELT POWER OFF PLATE		
129	NUT 3/8"		
130	FLAT WASHER 5/16"		
131	SPRING WASHER 5/16"		
132	SCREW 5/16" X 3/4"		
133	SCREW 3/16" X 3/4"		
134	NUT 3/16"		
135	CONNECTOR OF OIL CAP		
136	SHAFT OF OIL CAP		
137	FLAT WASHER 3/16"		
139	HEX SOCKET HEAD SCREW 5/16" X 1 1/2"		




7000	
ITEM NO	DESCRIPTION
101	UPPER FRAME COVER
103	HEAD SCREW M6
104	LEFT DOOR, UPPER FRAME
105	RIGHT DOOR, UPPER FRAME
106	DOOR LOCK
107	SCREW 5/16"
108	PLAIN WASHER 5/16"
109	RIGHT DOOR, LOWER FRAME
109-1	LEFT DOOR, LOWER FRAME
110	SCREW 1/4"
111	FRONT PROTECTION PLATE
112	SPRING WASHER 1/4"
114	SPRING WASHER 1/4"
115	HEAD SCREW M6
201	LIMIT SWITCH
202	LIMIT SWITCH PLATE
203	ROUND PHILLIP'S SCREW 5X10 MM
204	PLAIN WASHER 1/4"
205	FIXED PLATE
206	THICKNESSER
207	CAP 1/4 X 3/4
208	COVER
209	MAIN VERNIER FIXING BASE
210	MAIN VERNIER BASE
211	MAIN VERNIER
212	FLAT HEAD PHILLIP SCREW 1/4 X 1/2
213	NUT 5/16

8000
SINGLE PHASE



8000		8000	
ITEM NO	DESCRIPTION	ITEM NO	DESCRIPTION
101	ELECTRICAL CONTROL BOX	128-1	START SWITCH
102	HINGE	128-2	START SWITCH
103	ELECTRICAL CONTROL BOX OF DOOR	129-1	STOP SWITCH
104	BASE PLATE	129-2	STOP SWITCH
105	NUT 1/4"	130	POWER INDICATION LIGHT
106	SPRING WASHER 1/4"	131	EMERGENCY STOP SWITCH
107	CONTROL PANEL	132	WIRE COLUMN
108	PHILLIP'S SCREW M4 X 8MM	134	OVERLOAD RELAY
109	PROPORTIONAL CURRENT DEVICE		
110	TRANSFORMER: 3PH ONLY		
111	MAGNETIC CONTACTOR		
112	OVERLOAD RELAY		
113	FUSE		
114	OVERLOAD RELAY		
115	CONTACTOR		
115-1	CONTACTOR		
115-2	CONTACTOR WITH LOCK		
116	POWER WIRE TERMINAL		
117	PHILLIP'S SCREW M4 X 30MM		
118	TERMINAL PLATE		
119	PLAIN WASHER 1/4"		
120	SPRING WASHER 1/4"		
121	SCREW 1/4" X 1/2"		
122	PU CONNECTOR 1/2"		
123	PU CONNECTOR 3/4"		
124	CABLE CONNECTOR 1"		
126A	AMP METER		

9000



9000		9000	
ITEM NO	DESCRIPTION	ITEM NO	DESCRIPTION
101	FILTER CUP	128	FLEXIBLE HOSE
103	BRONZE CONNECTOR	129	FLEXIBLE HOSE
104	FLEXIBLE HOSE	131	FLEXIBLE HOSE
105	AIR SWITCH	132	FLEXIBLE HOSE
106	ELBOW	133	FLEXIBLE HOSE
107	SCREW 3/16"	134	FLEXIBLE HOSE
108	CONNECTOR	135	FLEXIBLE HOSE
109	SOLENOID VALVE	136	FLEXIBLE HOSE
110	T-JOINT	137	FLEXIBLE HOSE
111	CONNECTOR	138	FLEXIBLE HOSE
112	MULTIPLE HOLE CONNECTOR		
113	CONNECTOR		
114	BRONZE ELBOW		
115	CONNECTOR		
116	CONNECTOR		
117	THROTTLE VALVE		
118	CONNECTOR		
119	BRONZE CONNECTOR		
120	CONNECTOR		
121	CONNECTOR		
122	AIR SWITCH		
123	CONNECTOR		
124	CONNECTOR		
125	BUFFER		
126	BUFFER		
127	CONNECTOR		